## GIVE TO SCAFFOLD ERECTOR & USER OR POST ON JOB

## CODE OF SAFE PRACTICES FOR SUSPENDED POWERED SCAFFOLDS DEVELOPED FOR INDUSTRY BY THE Scaffold Industry Association, Inc. (SIA) and the Scaffold, Shoring & Forming Institute (SSFI)

It shall be the responsibility of all users to read and comply with the following common sense guidelines which are designed to promote safety in the erecting, dismantling and use of Suspended Powered Scaffolds. These guidelines do not purport to be all-inclusive nor to supplant or replace other additional safety and precautionary measures to cover usual or unusual conditions. If these guidelines in any way conflict with any state, local, provincial, federal or other government statute or regulation, said statute or regulation shall supersede these guidelines and it shall be the responsibility of each user to comply therewith.

## I.GENERAL GUIDELINES

**A. POST THESE SAFETY GUIDELINES** in a conspicuous place and be sure that all persons who erect, use, locate, or dismantle suspended scaffold systems are fully aware of them and also use them in tool box safety meetings.

**B. FOLLOW ALL EQUIPMENT MANUFACTURERS' RECOMMENDATIONS** as well as all state, local and federal codes, ordinances and regulations relating to suspended powered scaffolding. **C. SURVEY OF THE JOBSITE.** A survey shall be made of the jobsite by a competent person for hazards such as exposed electrical wires, obstructions that could overload or tip the suspended powered scaffold when it is raised or lowered, unguarded roof edges or openings, inadequate or missing tiebacks. Those conditions should be corrected before installing or using suspended powered scaffold systems.

**D. INSPECT ALL EQUIPMENT BEFORE EACH USE.** Never use any equipment that is damaged or defective in any way. Mark it or tag it as damaged or defective equipment and remove it from the jobsite. **E. ERECT AND DISMANTLE SUSPENDED POWERED SCAFFOLD EQUIPMENT** in accordance with design and/or manufacturer's recommendations.

**F. DO NOT ERECT, DISMANTLE OR ALTER SUSPENDED POWERED SCAFFOLD SYSTEMS** unless under the supervision of a competent person.

G. DO NOT ABUSE OR MISUSE SUSPENDED POWERED SCAFFOLD EQUIPMENT. Never overload platforms or hoists.

**H. ERECTED SUSPENDED POWERED SCAFFOLDS SHOULD BE CONTINUOUSLY INSPECTED** by the user to ensure that they are maintained in a safe condition. Report any unsafe condition to your supervisor.

I. NEVER TAKE CHANCES! IF IN DOUBT REGARDING THE SAFETY OR USE OF SUSPENDED SCAFFOLDS, CONSULT YOUR SCAFFOLD SUPPLIER.

J. NEVER USE SUPSENDED SCAFFOLD EQUIPMENT FOR PURPOSES OR IN WAYS FOR WHICH IT WAS NOT INTENDED.

K. CARE SHOULD BE TAKEN WHEN OPERATION AND STORING EQUIPMENT DURING WINDY CONDITIONS.

**L. SUSPENDED POWERED SCAFFOLD SYSTEMS** should be installed and used in accordance with the manufacturer's recommended procedures. Do not alter components in the field.

M. SUSPENDED POWERED PLATFORMS MUST NEVER BE OPERATED NEAR LIVE POWER LINES unless proper precautions are taken. Consult the power service company for advice. N. ALWAYS ATTACH FALL ARREST EQUIPMENT when working on suspended powered scaffolds.

**O. DO NOT WORK ON OR INSTALL SUSPENDED POWERED SCAFFOLDS** if your physical condition is such that you feel dizzy or unsteady in any way.

**P. DO NOT WORK ON SUSPENDED POWERED SCAFFOLDS** when under the influence of alcohol or illegal drugs.

II. GUIDELINES FOR ERECTION AND USE OF SUSPENDED SCAFFOLD SYSTEMS A. RIGGING

1. WEAR FALL PREVENTION EQUIPMENT when rigging on exposed roofs or floors.

- 2. ROOF HOOKS, PARAPET CLAMPS, OUTFIGGER BEAMS, OR OTHER SUPPORTING DEVICES must be capable of supporting the hoist machine rated load with a factor of safety of 4.
- **3. VERIFY THAT THE BUILDING OR STRUCTURE WILL SUPPORT** the suspended loads with a factor of safety of 4.
- 4. ALL OVERHEAD RIGGING must be secured from movement in any direction.
- 5. COUNTERWEIGHTS USED WITH OUTRIGGER BEAMS must be of a non-flowable material and must be secured to the beam to prevent accidental displacement.
- 6. OUTRIGGER BEAMS THAT DO NOT USE COUNTERWEIGHTS must be installed and secured on the roof structure with devices specifically designed for that purpose. Direct connections shall be evaluated by a competent person.
- 7. TIE BACK ALL TRANSPORTABLE RIGGING DEVICES. Tiebacks shall be equivalent in strength to suspension ropes.
- 8. INSTALL TIEBACKS AT RIGHT ANGLES TO THE FACE OF THE BUILDING and secure, without slack, to a structurally sound portion of the structure, capable of supporting the hoisting machine rated load with a safety factor of 4. IN THE EVENT TIEBACKS CANNOT BE INSTALLED AT RIGHT ANGLES, two tiebacks at opposing angles must be used to prevent movement.
- 9. RIG AND USE HOISTING MACHINES DIRECTLY UNDER THEIR SUSPENSION POINTS.
- **B. WIRE ROPE AND HARDWARE** 
  - **1. USE ONLY WIRE ROPE AND ATTACHMENTS** as specified by the hoisting machine manufacturer.
  - 2. ASSURE THAT WIRE ROPE IS LONG ENOUGH to reach to the lowest possible landing.
  - **3.** CLEAN AND LUBRICATE WIRE ROPE in accordance with the wire rope manufacturer's instructions.
  - 4. HANDLE WIRE ROPE WITH CARE.
  - 5. COIL AND UNCOIL WIRE ROPE in accordance with the wire rope manufacturer's instructions in order to avoid kinks or damage.
  - 6. TIGHTEN WIRE ROPE CLAMPS in accordance with the clamp manufacturer's instructions.
  - 7. DO NOT USE WIRE ROPE THAT IS KINKED, BIRDCAGED, CORRODED, UNDERSIZED OR DAMAGED IN ANY WAY. Do not expose wire rope to fire, undue heat, corrosive atmosphere, electricity, chemicals or damage by tool handling.
  - 8. USE THIMBLES AND SHACKLES AT ALLWIRE ROPE SUSPENSION TERMINATIONS.
  - **9. USE J-TYPE CLAMPS OR SWEDGE FITTINGS.** Do not use U-bolts. Retighten J Clamps under load and retighten daily.
  - **10. WIRE ROPES USED WITH TRACTION HOISTS MUST HAVE PREPARED ENDS.** Follow manufacturer's recommendations.
- C. POWER SUPPLY
  - 1. GROUND ALL ELECTRICAL POWER SOURCES AND POWER CORD CONNECTIONS and protect them with circuit breakers.
  - 2. USE POWER CORDS OF THE PROPER WIRE SIZE THAT ARE LONG ENOUGH for the job.
  - 3. POWER CORD CONNECTIONS MUST BE RESTRAINED to prevent their separation.
  - 4. USE STRAIN RELIEF DEVICES TO ATTACH POER CORDS TO THE SUSPENDED SCAFFOLD to prevent them from falling.
  - 5. PROTECT POWER CORDS AT SHARP EDGES.
  - 6. USE GFI WITH POWER TOOLS.
- D. FALL ARREST EQUIPMENT
  - 1. EACH PERSON ON A SUSPENDED POWERED SCAFFOLD must be attached to a separate fall arrest system unless the installation was specifically designed not to require one.
  - **2.** EACH LIFELINE MUST BE FASTENED to a separate anchorage capable of holding a minimum of 5000 pounds.

- **3. DO NOT WRAP LIFELINES AROUND STRUCTURAL MEMBERS** unless lifelines are protected and a suitable anchorage connection is used.
- 4. **PROTECT LIFELINES AT SHARP CORNERS** to prevent chafing.
- 5. RIG FALL ARREST SYSTEMS to prevent free fall in excess of six feet.
- 6. SUSPEND LIFELINES FREELY without contact with structural members or building façade.
- 7. USE LIFELINES OF SIZE AND CONSTRUCTION that are compatible with the rope grab used.
- 8. ASSURE A PROPERLY ATTACHED ROPE GRAB IS INSTALLED ON EACH LIFE LINE. Install in accordance with the manufacturer's recommendations.
- 9. KEEP FALL ARREST DEVICE POSTIONED ABOVE YOUR HEAD LEVEL.
- **10. USE ONLY FULL BODY HARNESSES** of the proper size and that are tightly fastened.
- **11. ASSURE FULL BODY HARNESS HAS LANYARD** attachment with D-ring at the center of your back.
- 12. CONSULT FALL PROTECTION SUPPLIER FOR INSPECTION PROCEDURE. INSPECT FALL PROTECTION ANCHORAGE/EQUIPMENT BEFORE EACH USE.
- **13. WHEN A SECONDARY WIRE ROPE SYSTEM IS USED,** a horizontal lifeline secured to two or more structural members of the scaffold may be used in lieu of vertical lifelines.

## E. DURING USE

- 1. USE ALL EQUIPMENT AND ALL DEVICES in accordance with the manufacturer's instructions.
- 2. DO NOT OVERLOAD, MODIFY OR SUBSTITUTE EQUIPMENT.
- **3. BEFORE COMMENCING WORK OPERATIONS** preload wire rope and equipment with the maximum working load, then retighten wire rope rigging clamps and recheck rigging to manufacturer's recommendations.
- 4. INSPECT ALL RIGGING EQUIPMENT AND SUSPENDED POWER SCAFFOLD SYSTEMS DAILY.
- 5. INSPECT WIRE ROPE DURING EACH ASCENT OR DESCENT FOR DAMAGE.
- 6. USE CARE TO PREVENT DAMAGE TO EQUIPMENT by corrosive or other damaging substances.
- 7. CLEAN AND SERVICE EQUIPMENT REGULARLY.
- 8. ALWAYS MAINTAIN AT LEAST (4) FOUR WRAPS OF WIRE ROPE ON DRUM TYPE HOISTS.
- 9. DO NOT JOIN PLATFORMS unless the installation was designed for that purpose.
- 10. ONLY MOVE SUSPENDED SCAFFOLDS HORIZONTALLY WHEN NOT OCCUPIED.
- **11. WHEN RIGGING FOR ANOTHER DROP** assure sufficient wire rope is available before moving the suspended scaffold system horizontally.
- 12. WHEN WELDING FROM SUSPENDED POWERED SCAFFOLDS:
  - **a.** Assure platform is grounded to structure
  - **b.** Insulate wire rope above and below the platform.
  - **c.** Insulate wire rope at suspension point and assure wire rope does not contact structure along its entire length.
  - **d.** Prevent the bitter end from touching the ground.